

1K Spray Can Usage Instructions

Product Features

- ◆ Easy to Use
- ◆ No equipment needed

Theoretical Solids Content:

Volume: N/A

Shelf Life*

(1) Year



Suitability

PLEASE READ MSDS INFORMATION PRIOR TO PROCEEDING

1K Spray Cans are suitable for use on small projects or minor repair touchups.

They are not a replacement for and epoxy or polyurethane coating.

Current 1K products

Endura 1K aerosols are currently available in the following products:

- ◆ IP-600 Universal Primer
- ◆ Precision enamel Topcoats
- ◆ Endura Alpha 1K Primer [F1KCC2150]

Using Endura 1K Spray

Shake until ball inside can breaks loose and rattles. Hold can at the top and swing bottom of can in a circles for at least 2 minutes, making ball travel around bottom groove. Shake can up and down occasionally.

Repeat shaking procedure for 10 seconds after each minute of painting.

Spray to test. Spraying distance 8-10 inches.

To prevent sagging

Move can with short dusting strokes releasing the button at the end of each stroke. Apply several thin coats.

Keep fingertips out of the spray so that droplets do not form.

Test spray paint for compatibility and color correctness and substrate compatibility prior to use.



Clean Up

To prevent the nozzle from clogging, turn can upside down and spray nozzle until only propellant is being sprayed (approx 2 seconds) between uses.

When work is finished, reverse aerosol and spray valve empty. The emptied aerosols are suitable for household collection.